

## Northring for First Class Windfahne

The adapter is installed between mast and sensor. The adapter is aligned to north by means of a bearing tube. After alignment the wind direction sensor is mounted onto the adapter. A pin in the adapter and a north boring in the base of the wind direction sensor guarantee that the sensor is aligned to north. There is no re-alignment necessary with replacement of the sensor.

## Specification

**Part number: 509619**

### General

Length	75 mm
Material	Alluminum anodized ( AlMgSi1 )
Weight	0.25 kg
Mounting	for mast $\varnothing$ 35 mm for sensor $\varnothing$ 35 mm

## Versions

No other versions of this product are available.

## Accessories

No accessories are available for this product.

