

Northring for Ultrasonic anemometer

The adapter is installed between mast and sensor. The adapter is aligned to north by means of a bearing tube. After alignment the sensor is mounted onto the adapter. A pin in the adapter and a north boring in the base of the anemometer guarantee that the sensor is aligned to north. There is no re-alignment necessary with replacement of the sensor.

Specification

Part number: 508696

General

Length	90 mm
Material	Alluminum anodized (AlMgSi1)
Weight	0.4 kg
Mounting	for mast Ø 50 mm for sensor Ø 50 mm

Versions

No other versions of this product are available.

Accessories

No accessories are available for this product.

