

Particulate Matter-Hygro-Thermo-Baro Sensor Compact

Short - Instruction for Use First Steps – Start up

1.1007.54.78x

At start of software version V3.13



Dok. No. 022034/07/24

THE WORLD OF WEATHER DATA



Safety Instructions

- Before operating with or at the device/product, read through the operating instructions. This manual contains instructions which should be followed on mounting, start-up, and operation.
 - A non-observance might cause:
 - failure of important functions
 - endangerment of persons by electrical or mechanical effect
 - damage to objects
- Mounting, electrical connection and wiring of the device/product must be carried out only by a qualified technician who is familiar with and observes the engineering regulations, provisions and standards applicable in each case.
- Repairs and maintenance may only be carried out by trained staff or Adolf Thies GmbH & Co. KG. Only components and spare parts supplied and/or recommended by Adolf Thies GmbH & Co. KG should be used for repairs.
- Electrical devices/products must be mounted and wired only in a voltage-free state.
- Adolf Thies GmbH & Co KG guarantees proper functioning of the device/products provided that no modifications have been made to the mechanics, electronics or software, and that the following points are observed:
- All information, warnings and instructions for use included in these operating instructions must be taken into account and observed as this is essential to ensure trouble-free operation and a safe condition of the measuring system / device / product.
- The device / product is designed for a specific application as described in these operating instructions.
- The device / product should be operated with the accessories and consumables supplied and/or recommended by Adolf Thies GmbH & Co KG.
- Recommendation: As it is possible that each measuring system / device / product may, under certain conditions, and in rare cases, may also output erroneous measuring values, it is recommended using redundant systems with plausibility checks for **security-relevant applications**.

<u>Environment</u>

 As a longstanding manufacturer of sensors Adolf Thies GmbH & Co KG is committed to the objectives of environmental protection and is therefore willing to take back all supplied products governed by the provisions of "*ElektroG*" (German Electrical and Electronic Equipment Act) and to perform environmentally compatible disposal and recycling. We are prepared to take back all Thies products concerned free of charge if returned to Thies by our customers carriage-paid.



• Make sure you retain packaging for storage or transport of products. Should packaging however no longer be required, please arrange for recycling as the packaging materials are designed to be recycled.

Documentation

- © Copyright Adolf Thies GmbH & Co KG, Göttingen / Germany
- Although these operating instructions have been drawn up with due care, **Adolf Thies GmbH & Co KG** can accept no liability whatsoever for any technical and Typeographical errors or omissions in this document that might remain.
- We can accept no liability whatsoever for any losses arising from the information contained in this document.
- Subject to modification in terms of content.
- The device / product should not be passed on without the/these operating instructions.



Table of contents

1 Models		
2 Electrical Installation		
2.1 Connection of the	neasurement electronics	4
2.1.1 Connection Dia	agram	5
2.1.2 Plug Assignme	nt	5
2.1.3 Cable for the n	neasurement electronics	5
2.1.4 Plug and Cable	e Mounting	6
2.2 Connection of vent	ilation	7
2.2.1 Cable assignm	ent	7
2.2.2 Fan status		7
3 Technical Data		
4 Dimensional Drawing		10
4.1 Table and Figures	Overview	11
5 More Information / Doc	uments as download	11

The list of tables and figures can be found in the appendix.

1 Models

Order no.	Serial interface / Data format / Analogue Output	Supply	Model with
1.1007.54.780	RS 485 HD / THIES ASCII / -	2 x 12 30V DC	Measuring electronics
1.1007.54.781	RS 485 HD / MODBUS RTU / -	2 x 12 30V DC	with plug, weather and ra- diation protection with permanently connected 5m cable.

The following parts are included in the scope of delivery:

- 1 x Particulate matter-hygro-thermo-baro sensor compact
- 1 x Cable for the measuring electronics
- 1 x Instructions for use: short version (included in the package)
- 1 x Factory settings (included in the package)

The inductions for use for the particulate matter-hygro-thermo-baro sensor compact are available for download under the following link:

https://www.thiesclima.com/db/dnl/1.1007.54.78x_Particulate_Hygro_Thermo_Baro_Compact_FirstSteps_eng



2 Electrical Installation

The electrical installation of the particulate matter-hygro-thermo-baro sensor is divided into two parts. The measuring electronics are connected via a plug connection, which is used both for the power supply and for communication. The ventilation of the weather and radiation protection is connected via a cable that is permanently connected to the device.



2.1 Connection of the measurement electronics

Note:

The RS485 interface is galvanically connected to the supply voltage. The sensor internally contains 2 bias resistors of 47kOhm each betweem RxD and +3.4V and between TxD and GND, respectively.



2.1.1 Connection Diagram



* Outputs 1 to 3 only have a function with analogue output sensors and are configurable

2.1.2 Plug Assignment

PIN	Name	Function	Core color ¹	Mating con- nector
1	+Us	Supply voltage	white	View on the
2	GND	Ground	brown	soldered joint of
3	Data+	RS485 Data + (A)	green	the counter
4	Data-	RS485 Data – (B)	yellow	piug
5	NC	Not connected	gray	
6	NC	Not connected	rose	
7	NC	Not connected	blue	
Ŧ	Shield	-	green – yellow	

Table 1: Socket assignment of the connection cable 510641

2.1.3 Cable for the measurement electronics

The cable to be connected should have the following properties: 4 cores, core cross-section 0.25mm², cable diameter 6 ... 8mm, resistant to ultraviolet rays, overall shielding.

¹ with cable assembly from Thies Clima (accessories). Depending on the variant, the unused cores may not be available



The following procedure is recommended for using the cable shield:

Lay the cable shield between the sensor and the data acquisition system (e.g., datalogger) on both sides. Ground the data acquisition system.

2.1.4 Plug and Cable Mounting

A cable for the measurement electronics is included. If a different cable is used, a socket of type Bender Series 423, 7 positions, has to be employed according to the following instructions:





2.2 Connection of ventilation

2.2.1 Cable assignment

The permanently connected cable for the ventilation is assigned as follows:



Figure 1: Ventilation connection diagram

2.2.2 Fan status

The status output signals the status of the fan. A high signal indicates that the fan is working correctly, if the output is 0V there is a malfunction.



Figure 2: Connection of the status output

The voltage U_{Status} takes on following values:

Operating condition	Voltage U _{Status}
Normal operation	4,9 5,2V
Fan is stiff or blocked	0,5 0,6V
No supply voltage or malfunction	0V

Figure 3: Ventilation status output values



3 Technical Data

Relative Humidity	
Measuring range	0 100% rel. Humidity
Accuracy	Тур. ± 1.5% г. Н. @ 25 °С and < 80% г. Н.
-	2% r. H. in the complete measuring range
Long-term stability	Typ. < 0.25 % rel. humidity / year
Settling time ¹	≤ 35sec
Absolute Humidity	
Accuracy ²	Better than ± 0.15g/m ³ @ -4020 °C
-	Better than 6 % of the measured value @ -20 +60 °C
Air temperature	
Measuring range	-40 +60 °C
Accuracy	± 0.1°C @ -40 +60 °C
Long-term stability	Better than 0.03 °C / Year
Settling time ¹	≤ 41sec
Dew point temperature	
Accuracy ²	Better than ±2.0 °C @ 10 100 % rel. humidity, -40 +60 °C
Barometric pressure	
Measuring range	300 1200hPa
Accuracy	± 0.25hPa @ -20 +60 °C @ 800 1100hPa
	± 0.50hPa @ -20 +60 °C @ 600 800hPa
Long-term stability	± 0.3hPa / Year
Setting time ¹	≤ 5s
Particulate matter	
Measuring range	0 1000µg/m³
Accuracy (without fog)	PM2.5 @ -10+60 °C
	± 10µg/m³ @ 0 100µg/m³
	\pm 10 % of the measured value @ 100 1000µg/m ³
	PM10 @ -10+60 °C
	± 25μg/m³ @ 0 100μg/m³
	± 25 % of the measured value @ 100 1000µg/m ³
Long-term stability	Better than ±1.25µg/m [°] /Year
Electrical output	
	KS 485 HD

Serial interface	Туре	RS485			
	Operating mode	Half duplex mode			
	Data format ¹	8N1, 8N2, 8E1, 8E2, 8O1, 8O2, 7E1, 7N1			
	Baud rate	2400, 4800, 9600, 19200, 38400, 57600			
Resolution	Air pressure:	0.01hPa (max.)			
(Telegram and interpreter	Humidity:	0.1% rel. humidity			
dependent)	Temperature:	0.01°C (max.)			
	Particulate matte	er: 0.1µg/m ³			
Measurement rate	1s				
Accuracy	See above				
Supply voltage	Voltage: 12 30	DV DC			
	Measuring electr	onics via plug socket			
	Ventilation via permanently connected cable				
Power consumption	Measurement electronics:				
	typ. 450mW				
	max. 500mW				
	Ventilation:				
	2W				

¹ When using the MODBUS command interpreter, only data formats with 8 data bits can be used.



Further information	
Cable for measurement	LiYCY 4 x 0.25mm ² shielded, UV-resistant, Ø 6 8mm
Type of connection	Measuring electronics: Cable with plug for data transmission and power supply Weather and thermal radiation shield: fixed 5m cable
Admissible environmental	-20 +70 °C
conditions	0 100 rel. humidity, including condensation
Dimensions	See 13. Dimensional drawing
Weight	Approx. 1,25kg
Type of protection	IP53
Housing material	Stainless steel, polycarbonate

1)

¹⁾ $\tau_{63\%}$ ²⁾ Derived from the accuracies of humidity and air temperature.



4 Dimensional Drawing



	Α	В	С	D	Е	F	G	H ¹	K ²
	[mm]	[mm]	[KS]						
1.1007.54.780	Ø120	317	222	70	82	99	Ø35-50	Ø15-21	36

¹⁾H = Sensor diameter; ²⁾KS = Key size



4.1 Table and Figures Overview

Table overview:

Table 1: Socket assignment of the connection cable 510641	5
---	---

Figures overview:

Figure 1: Ventilation connection diagram7	•
Figure 2: Connection of the status output7	•
Figure 3: Ventilation status output values7	•

5 More Information / Documents as download

Further information can be found in the short instructions for use. These document and also the instruction for use are available for download under the following links.

Short instruction for use

https://www.thiesclima.com/db/dnl/1.1007.54.78x_Particulate_Hygro_Thermo_Baro_Compact_FirstSteps_eng

Instruction for use

https://www.thiesclima.com/db/dnl/1.1007.54.78x_Particulate_Hygro_Thermo_Baro_Compact_eng.pdf



Please contact us for your system requirements. We advise you gladly.

ADOLF THIES GMBH & CO. KG

Meteorology and environmental metrology Hauptstraße 76 · 37083 Göttingen · Germany Phone +49 551 79001-0 · Fax +49 551 79001-65 info@thiesclima.com

www.thiesclima.com

